



- Grease
- Threadlocker
- Grease + Threadlocker

Apply grease to the shaft, and locker to the threads

ITEM No.	DESCRIPTION	QTY.	PART NUMBER	TORQUE
1	FRAME	1		
2	BATTERY BOLT + WASHER M5x16L	2	099.23011	4Nm
3	BATTERY COVER	1	SET 6	
4	BOLT M3x8L M-S	9	SET 3 / 6 / 2	1Nm
5	FRAME RUBBER PROTECTOR	1	099.23006	
6	CHAIN STAY RUBBER PROTECTOR	1	099.23007	
7	HANGER NUT	1	SET 1	4Nm
8	EGRAVEL HANGER	1	SET 1	
9	EGRAVEL LEFT ADAPTOR MOTOR	1	SET 2	
10	MOTOR ADAPTOR	1	SET 3	
11	SEAT CLAMP	1	SET 4	
12	SEAT CLAMP BOLT	1	SET 4	8Nm
13	REAR AXLE 142x12	1	099.23009	12Nm
14	BRAZE ON	1	SET 5	
15	STEEL HEX DRIVE FLAT HEAD SCREW M4x8L-M5	2	SET 5	2Nm
16	BLACK FORK	1	099.23010	
17	FRONT AXLE	1	099.23008	12Nm
18	CONTROLER BOLT M3x10L-SP-SB	1		1Nm
19	MOTOR HUB PORT BOLT M3x6L P-S	2		1 Nm
20	TOP INTERNAL BATTERY SPACER	1	099.23042	
21	BOTTOM INTERNAL BATTERY SPACER	1	099.23043	
22	BRAZE ON COVER	1	099.23044	
23	FORK/TOP TUBE RIVET PLUG	8	099.23045	



PART NUMBER	DESCRIPTION	COMPONENTS
099.00066	SET 1: HANGER M076 + NUT	HANGER (x1) / HANGER NUT (x1)
099.23001	SET 2: LEFT DROPOUT	E GRAVEL LEFT ADAPTOR MOTOR (x1) / SCREW BOLT (x3)
099.23002	SET 3: LEFT DRIVE ADAPTOR	MOTOR ADAPTOR (x1) / SCREW BOLT (x2)
099.23003	SET 4: SEAT CLAMP	SEAT CLAMP (x1) / SCREW BOLT (x1)
099.23004	SET 5: FRONT DERAILLEUR BRAZE ON	BRAZE ON (x1) / SCREW BOLT (x2)
099.23005	SET 6: BATTERY COVER	BATTERY COVER (x1) / SCREW BOLT (x2)